




APPLIED ENGINEERING PRODUCTS


(203) 776-2813 FAX (203) 776-8294

www.aepconnectors.com


Assembly Instructions



1. TRIM CABLE JACKET AS SHOWN.
2. SLIDE COUPLING NUT ONTO CABLE, THREADS FORWARD.



3. INSERT CABLE INTO BODY UNTIL IT BOTTOMS. SOLDER CABLE JACKET TO CONNECTOR BODY. DO NOT DISTURB JOINT UNTIL IT HAS COOLED. CLEAN FLUX RESIDUE.
4. TRIM DIELECTRIC FLUSH TO BODY AND POINT CENTER CONDUCTOR AS SHOWN.



5. INSTALL GASKET ON FRONT FACE OF BODY.
6. SLIDE COUPLING NUT FORWARD AND SNAP ON "C" RING.

AIS-235-B102

REV. A

4740