


APPLIED ENGINEERING PRODUCTS


(203) 776-2813 FAX (203) 776-8294

www.aepconnectors.com

Assembly Instructions



1. TRIM CABLE AS SHOWN ABOVE.



2. INSERT CABLE INTO BODY UNTIL IT BOTTOMS, MAKING SURE CENTER CONDUCTOR OF CABLE GOES INTO CONTACT.
3. SOLDER JACKET TO CONNECTOR BODY.
DO NOT DISTURB JOINT UNTIL IT HAS COOLED.
CLEAN FLUX RESIDUE.